

12V 100AH

(100A BMS)

PRODUCT MANUAL

Lithium Iron Phosphate (LiFePO_4) Battery

www.jsdsolar.com



support@jsdsolar.com



0086-755-89918655

PRODUCT OVERVIEW

12.8V 100AH BATTERY

Operating Voltage: 12.8V

Charging Voltage: 14.4±0.2V

Recommend Charge Current: 20A (0.2C)

Max Continuous Discharge Current: 100A

Max, Continuous Output Power: 1280W



ADDITIONAL COMPONENTS

M8(14mm) Terminal Bolts *2

The terminal bolts are used to secure multiple cable lugs to a single battery terminal. The bolts can be replaced with M8 bolts of other lengths based on actual needs.



Insulating Caps for Bolts *2

IMPORTANT SAFETY INSTRUCTION

Please keep the battery away from heat sources, sparks, flames, and hazardous chemicals.

Maintain Adequate Ventilation and Heat Dissipation

Place the battery in a well-ventilated area with sufficient heat dissipation to prevent overheating and damage.

Size the Battery Cables and Connectors Appropriately

Use high-stranded copper connectors and heavy gauge cables to handle possible battery loads. Make sure to keep identical cable lengths. Avoid accidents caused by unsuitable connectors or cables that make the connection a heat source during battery operation.

Please tighten all cable connections, as loose cable connections can cause terminal meltdown or fire.

DO NOT puncture, drop, crush, burn, penetrate, shake, or strike the battery.

The battery should be securely fastened during handling to prevent impact or dropping.

It should be safely secured to a solid plane and the cables safely tied to a suitable location to avoid arcing and sparking due to friction.

DO NOT press it by placing heavy stuff on top of it for long periods, which may damage it due to an internal short circuit.

DO NOT immerse the battery in water whether the battery is in use or on standby.

DO NOT open, dismantle, or modify the battery.

DO NOT touch the exposed electrolyte or powder if the battery casing is damaged.

Uncovered electrolyte or powder that has contacted the skin or eyes MUST be flushed out with plenty of clean water immediately. Seek medical attention afterward.

Avoid Short Circuit

Please use circuit breakers, fuses, or disconnects that have been properly sized by certified electricians, licensed installers, or regional code authorities to protect all the electrical equipment in your system. The battery has a built-in battery management system (BMS) that protects the battery cells from over-charge, over-discharge, and over-current, however this alone will not protect your system from severe electrical conditions.

Trained and certified technicians are required for safe and reliable installation. This product manual can only serve as a guideline as it cannot cover all possible scenarios.

Verify Correct Polarity

Please verify the polarity before connecting the wiring. Reverse polarity can and will destroy the battery and other electrical equipment. Use a multimeter to determine proper polarity.

Avoid Exposed Metal Terminals or Connectors

The terminals of this battery are always live. Avoid exposed metal terminals or connectors; DO NOT place tools on the terminals or touch them with bare hands; DO NOT short circuit or use outside of specified electrical ratings.

DO NOT dispose of the battery as household waste. Please use recycling channels in accordance with local, state, and federal regulations.

WARNING

Batteries are potentially dangerous and proper precautions must be taken during operation and maintenance.

Improper use of the battery can lead to battery failure or other potential damage.

Improper configuration, installation, or use of related equipment in the battery system may damage the battery and other related equipment.

Please wear proper personal protective equipment when working on the battery.

Battery installation and maintenance must be performed by trained and certified technicians.

Failure to follow the warnings above can result in potential damage.

**If you have any questions or need any help,
please feel free to contact us (and leave your contact phone number)
at aliexpress@jsdsolar.com,
we will offer phone or email support in 12hrs.**

BATTERY-PACK MAIN SAFETY INSTRUCTION

Cell	Prismatic LiFePO ₄ Battery
Nominal Voltage	12.8V
Rated Capacity	100Ah
Energy	1280Wh
Internal Resistance	≤40mΩ
Cycle Life	6000 times (25°C, 0.2C, 100% DOD)
Battery Management System (BMS) Board	100A
Charge Method	CC/CV
Charge Voltage	14.4V±0.2V
Recommend Charge Current	20A (0.2C)
Max. Continuous Charge Current	100A
Max. Continuous Discharge Current	100A
Max. Continuous Output Power	1280W
Dimension	260*168*211mm

Housing Material	ABS (Flame Retardant Plastic)
Protection Class	IP65
Temperature Range	Charge: 0°C to 50°C/32°F to 122°F
	Discharge: -20°C to 60°C/-4°F to 140°F
	Storage: -10°C to 50°C/14°F to 122°F
Low temperature protection	Yes
Bluetooth	N/A



THINGS TO KNOW BEFORE USING

When using the battery, please be careful to **avoid metal or conductive objects touching the positive and negative** poles of the battery at the same time, otherwise it may cause a short circuit.

Tightly screw in the post bolts. and it could not be mounted upside down. If you need to mount the battery at its side, please contact aliexpress@jsdsolar.com to confirm the direction.

Tightly screw in the post bolts. Having loose battery terminals will cause the terminals to build up heat resulting in damage to the battery.

This battery is not intended to be used to start any devices, please **DO NOT use it as a starting battery.**


Suggestions for **Long-term Storage:**

● Temperature

The battery can be operated at a temperature of -20°C to 60°C/-4°F to 140°F, and a temperature between **10°C to 35°C/ 50°F to 95°F** is ideal for long-term storage. Store in a fireproof container and away from children.

● Capacity

For a longer-lasting product, it is best to store your battery at a 50% charge level and recharge every three months if it is not going to be used for a long time.




CHARGING METHODS

BATTERY CHARGING LOGIC

The material characteristics of the LiFePO₄ battery determine that its charging curve is obviously different from that of a lead-acid battery. Compared with a lead-acid battery, the LiFePO₄ battery has a simpler charging process and mode. Therefore, it is recommended to select LiFePO₄ for your charging mode.

If LiFePO₄ mode is not available, please refer to the recommend edparameters on Page 05~06 for setting.

LIFEPO4 AND LEAD-ACID BATTERY CHARGING CURVE



LIFEPO4 BATTERY CHARGING MODE

● CC(Constant Current) Phase (T1)

In the beginning, a discharged battery will be charged with a constant current and voltage will be climbing steadily until reaching the constant voltage setpoint which varies for different charging methods.

● CV (Constant Voltage) Phase (T2)

The battery maintains a constant voltage during this phase while the current gradually decreases to 2A (0.02C) which is also known as tail current. At this point, the charging is cut off and the battery is fully charged.

① Tail Current (A)= Battery Capacity*0.02C.E.g, 100Ah*0.02C= 2A tail current.

SOLAR PANEL(S)& CONTROLLER

Solar Panel

★ **Recommend Power:** $\geq 300W$

- The battery can be fully charged in one day (with effective sunshine 4.5hrs/day) by 300W solar panels.
- It may take more than one day to fully charge the battery by $\geq 300W$ solar panels since the duration and intensity of light would be a great factor for their charging efficiency.

Controller

★ **Recommend Charging Current:**

20A(0.2C)	The battery will be fully charged in around 5hrs to 100% capacity.
50A(0.5C)	The battery will be fully charged in around 2hrs to around 97% capacity.

★ **Recommend Charging Mode:** **12V(14.6V)LI (LiFePO4)**

Controller Settings

Refer to the below parameters if you need to manually set up your controller. As different types of batteries have different charging modes (refer to Page 04), [it is recommended to set only the following parameters for LiFePO4 batteries](#). The settings for other types of batteries do not apply to LiFePO4 batteries except for the following settings.

CHARGING	Charge /Bulk /Boost Voltage	14.4V/14.6V
	Absorption Voltage	14.4V/14.6V
	Over Voltage Disconnect	15V
	Over Voltage Reconnect	14.2V
	Tail Current	2A (0.02C)
DIS-CHARGING	Under Voltage Warning	11.6V
	Under Voltage Recover	10.8V
	Low Voltage Disconnect	9.8V
	Low Voltage Reconnect	12.4V

BATTERY CHARGER

Use 14.6V lithium iron phosphate (LiFeP04) battery charger to maximize the capacity.


★ **Recommend Charging Voltage:** Between 14.2V to 14.6V

★ **Recommend Charging Current:**

<u>20A(0.2C)</u>	The battery will be fully charged in around 5hrs to 100% capacity.
<u>50A(0.5C)</u>	The battery will be fully charged in around 2hrs to around 97% capacity.

Tips

- ① Connect the charger to the battery before connecting it to the grid power in case of sparks.
- ② It's recommended to disconnect the charger from the battery after fully charging.



ALTERNATOR /GENERATOR


LiTime battery can be charged by an alternator or generator.

If the alternator/generator supports DC output, a DC-to-DC charger needs to be added between the battery and the generator; if the alternator/generator supports AC output, please refer to the recommendations in "Battery Charger" above to add a suitable battery charger between the battery and the generator.

★ **Recommend Charging Voltage:** Between 14.2V to 14.6V

★ **Recommend Charging Current:**

<u>20A(0.2C)</u>	The battery will be fully charged in around 5hrs to 100% capacity.
<u>50A(0.5C)</u>	The battery will be fully charged in around 2hrs to around 97% capacity.



SERIES/PARALLEL CONNECTION

THE PREMISE OF CONNECTION

To connect in series or /and parallel, batteries should meet the below conditions:

- identical batteries with the same battery capacity (Ah) and BMS (A);
- from the same brand (as lithium battery from different brands has their special BMS);
- purchased in near time (within one month).


LIMITATION FOR SERIES/PARALLEL CONNECTION

Support connecting up to 16 identical batteries for up to:


4 in series as 48V(51.2V)battery system/

4 in parallel as 400Ah battery system.

Series Connection 48V(51.2V)100Ah




Parallel Connection 12V(12.8V)400Ah



HOW TO CONNECT BATTERIES

Step1 Wear Insulating Gloves

Wear insulating gloves for protection before connecting. Please pay attention to operation safety in the process of connection.



Step2 Voltage Balancing Before Connection


Below two steps are necessary to reduce the voltage difference between batteries and let the battery system perform the best of it in series or/ and in parallel.

Step
1

Fully charge the batteries separately.
(voltage at rest: >13.33V)

Step
2

Connect all of the batteries in parallel, and leave them together for **12~24hrs**




Step
3

They're now ready for the **connection.**

Step3 Battery-to-Battery Connection


- #1 Connect Batteries in Series **+** to **-**



After series connection, the **voltage** of the battery system will be doubled according to the number of batteries you connect.
E.g. If two 12V 100Ah batteries are connected in series, the battery system will be 24V(25.6V)100Ah.

Step3 Battery-to-Battery Connection

- #2 Connect Batteries in Parallel **+** to **-** **-** to **-**




After parallel connection, the **capacity** of the battery system will be doubled according to the number of batteries you connect.
E.g. If two 12V 100Ah batteries are connected in parallel, the battery system will be 12V(12.8V) 200Ah.

• #3 Connect Batteries Both in Series & Parallel

Connect in parallel first, then series


Step
1

Connect the batteries in **parallel**



Step
2


Connect the paralleled battery systems in **series**



Step4 Total input & Output Connection

Use two **copper bars** (instead of battery terminals) to connect all the positive and negative output/input cables, ensuring that the input & output currents of each battery are balanced. (Not required when connecting batteries only in series.)

It is not recommended to use one terminal as the total positive or negative output/input of the battery system as the connected terminals may heat up or even melt if the total output/input current of the battery system is too high.




① As $\ominus$ of ① / ③ / ⑤ / ⑦ is connected in series with $\oplus$ of ② / ④ / ⑥ / ⑧, please do not connect $\ominus$ of ① / ③ / ⑤ / ⑦ with $\ominus$ of load or $\oplus$ of ② / ④ / ⑥ / ⑧ with $\oplus$ of load, otherwise the battery system will fail to connect in series.

② Please do not connect in reverse order, which may affect the use of the batteries


Step 5 Rebalancing Every 6 Months

It is recommended to rebalance the battery voltage every six months following Step 2 on Page 10 if you're connecting multiple batteries as a battery system, as there might be voltage differences after six months of the battery system running.



Wiring Diagrams

2P2S	Battery System	24V(25.6V)200Ah
	Energy	5120Wh
	Max. Continuous Charge /Discharge Current	200A
	Max. Continuous Load Power	5120W



WHAT TO DO WHEN THE BATTERY STOPS WORKING?

When the battery




It has 85% chances that BMS has shut it off for protection, and you could try one of below ways to activate the battery.

GENERAL STEPS

If the BMS has cut off the battery for protection, follow the below steps to activate it.

Step
1


Cut off all the connections from the battery



Step
2

Leave the battery aside for 30mins

Then the battery will automatically recover itself to normal voltage (>10V) and can be used after fully charged.




If the battery is unable to recover itself after the above steps, please try activating by **ONE OF BELOW TWO METHODS.**

After activated (voltage > 10V) and fully charged by the normal charging method, it can be used normally.

Method ①


Use a charger with a 0V charging function ① to fully charge the battery.



① The charger can charge the battery starting from 0V.

Method ②

Connect an 18V~36V solar panel to charge ① the battery for 3~10s in sunny daytime.





www.jsdsolar.com



 support@jsdsolar.com

 0086-755-89918655